



ASSEMBLY SEQUENCE:
 STEP1 : ASSEMBLY MTI-P45-ADR AND MTI-45 SERIES.
 STEP2 : ASSEMBLY MTL-P2S45(MTL-PL45) AND MTI-P45-ADR.

INSTRUCTION FOR USE